# Open-pit mining



<u>Rock blasting</u> at the large open-pit <u>Twin Creeks gold</u> <u>mine</u> in <u>Nevada</u>, United States. Note the size of the excavators for scale (foreground, left), and that the bottom of the mine is not visible.



I ne glant <u>bucket-wneel excavator</u> in the German Rhineland coal mines are among the world's biggest land vehicles.

**Open-pit**, **open-cast** or **open cut mining** is a <u>surface mining</u> technique of extracting <u>rock</u> or <u>minerals</u> from the earth by their removal from an open pit or <u>borrow</u>.

This form of <u>mining</u> differs from extractive methods that require tunnelling into the earth, such as <u>long</u> <u>wall mining</u>. Open-pit mines are used when deposits of commercially useful ore or rocks are found near the surface. It is applied to ore or rocks found at the surface because the <u>overburden</u> is relatively thin or the material of interest is structurally unsuitable for tunnelling (as would be the case for sand, cinder, and gravel). In contrast, minerals that have been found underground but are difficult to retrieve due to hard rock, can be reached using a form of underground mining.<sup>[1]</sup>

To create an open-pit mine, the miners must determine the information of the ore that is underground. This is done through drilling of probe holes in the ground, then plotting each hole location on a map. The information gained through the holes with provide an idea of the vertical extent of the ore's body. This vertical information is then used to pit tentative locations of the benches that will occur in the mine.<sup>[2]</sup> It is important to consider the grade and economic value of the ore in the potential pit.<sup>[3]</sup> Open-pit mines that produce <u>building materials</u> and <u>dimension stone</u> are commonly referred to as "<u>quarries</u>."

Open-pit mines are typically enlarged until either the <u>mineral resource</u> is exhausted, or an increasing ratio of overburden to ore makes further mining uneconomic. When this occurs, the exhausted mines are sometimes converted to <u>landfills</u> for disposal of solid wastes. However, some form of water control is usually required to keep the mine pit from becoming a lake, if the mine is situated in a climate of considerable <u>precipitation</u> or if any layers of the pit forming the mine border productive <u>aquifers</u>.

Open-pit mining is to be considered one of the most dangerous sectors in the industrial world. It causes significant effects to miners health, as well as damage to the ecological land. Open-pit mining causes changes to vegetation, soil, and bedrock, which ultimately contributes to changes in surface hydrology, groundwater levels, and flow paths.<sup>[4]</sup> Additionally, open-pit produces

harmful pollutants depending on the type of mineral being mined, and the type of mining process being used.

### Extraction



Note the angled and stepped sides of the <u>Sunrise</u> <u>Dam Gold Mine</u>, Australia.



#### <u>Play media</u>

Heavy machinery extracting lignite from <u>Garzweiler</u>

Open-cast mines are dug on benches, which describe vertical levels of the hole. The interval of the benches depends on the deposit being mined, the mineral being mined, and the size of the machinery that is being used. Generally, large mine benches are 12 to 15 metres thick.<sup>[5][6]</sup> In contrast, many quarries do not use benches, as they are usually shallow.<sup>[7]</sup> Mining can be conducted on more than one bench at a time, and access to different benches is done with a system of ramps. The width of each bench is determined by the size of the equipment being used, generally 20-40

metres wide.<sup>[8]</sup> Downward ramps are created to allow mining on a new level to begin. This new level will become progressively wider to form the new pit bottom.<sup>[9]</sup>

Most walls of the pit are generally mined on an angle less than vertical. Waste rock is stripped when the pit becomes deeper, therefore this angle is a safety precaution to prevent and minimize damage and danger from rock falls. However, this depends on how weathered and eroded the rocks are, and the type of rocks involved. It also depends on the amount of structural

weaknesses occur within the rocks, such as a <u>faults</u>, <u>shears</u>, joints or <u>foliations</u>.

The walls are stepped. The inclined section of the wall is known as the batter, and the flat part of the step is known as the bench or berm. The steps in the walls help prevent rock falls continuing down the entire face of the wall. In some instances additional ground support is required and rock bolts, cable bolts and shotcrete are used. De-watering bores may be used to relieve water pressure by drilling horizontally into the wall, which is often enough to cause failures in the wall by itself.<sup>[10]</sup>

A haul road is usually situated at the side of the pit, forming a ramp up which <u>trucks</u> can drive, carrying <u>ore</u> and waste rock.<sup>[11]</sup>

#### Waste

Open-pit mines create a significant amount of waste. Almost one million tons of ore and waste rock can move from the largest mines per day, and a couple thousand tons moved from small mines per day.<sup>[12]</sup> There is generally four main operations in a mine that contribute to this load: <u>drilling</u>, blasting, loading and <u>hauling</u>. Waste rock is hauled to a waste dump. Waste dumps can be piled at the surface of the active pit, or in previously mined pits.

Leftover waste from processing the ore is called tailings, and is generally in the form of a slurry. This is pumped to a tailings dam or settling pond, where the water is reused or evaporated. Tailings dams can be toxic due to the presence of unextracted sulfide minerals, some forms of toxic minerals in the gangue, and often cyanide which is used to treat gold ore via the cyanide leach process. If proper environmental protections are not

in place, this <u>toxicity</u> can harm the surrounding environment.<sup>[13]</sup>

## Pollutants

Open-pit mining involves the process of disrupting the ground, which leads to the creation of air pollutants. The main source of air pollutants comes from the transportation of minerals, but there are various other factors including drilling, blasting and the loading and unloading of overburden.<sup>[14]</sup> These type of pollutants cause significant damage to public health and safety in addition to damaging the air quality. The inhalation of these pollutants can cause issues to the lungs

and ultimately increase mortality.<sup>[15]</sup> Furthermore, the pollutants affect flora and fauna in the areas surrounding openpit mines.

Open-pit gold mining is one of the highest potential mining threats on the environment as it affects the air and water chemistry. The exposed dust may be toxic or radioactive, making it a health concern for the workers and the surrounding communities.<sup>[16]</sup>

## Untopping

A form of open-cast quarrying may be carried out as 'untopping'. This is done where a previous underground mine is becoming uneconomic or worked-out, but still leaves valuable rock in place, often as a result of <u>room and pillar</u> <u>mining</u>. Untopping removes the overburden from above this, opens up the mine from above, and then allows the previously 'trapped' minerals to be won.

Untopping was a feature of <u>Welsh slate</u> workings in the 1930s and 2000s, where Martyn Williams-Ellis, manager at <u>Llechwedd</u> found that earlier Victorian workings could be kept profitable with the newly mechanised techniques for bulk excavation to extract their pillars, and more recently across a number of worked-out mines.<sup>[17]</sup>

## Rehabilitation



Opencut coal mine loadout station and reclaimed land at the <u>North Antelope Rochelle coal mine</u> in <u>Wyoming</u>, United States.

After mining finishes, the mine area may undergo <u>land rehabilitation</u>. Waste dumps are contoured to flatten them out, to further stabilize them. If the ore contains <u>sulfides</u> it is usually covered with a layer of <u>clay</u> to prevent access of <u>rain</u> and <u>oxygen</u> from the air, which can oxidize the sulfides to produce <u>sulfuric</u> acid, a phenomenon known as acid mine <u>drainage</u>.<sup>[18]</sup> This is then generally covered with soil, and vegetation is planted to help consolidate the material. Eventually this layer will erode, but it is generally hoped that the rate of leaching or acid will be slowed by the cover such that the environment can handle the load of acid and associated heavy metals.<sup>[19]</sup> There are no long term studies on the success of these covers due to the relatively short time in which large scale open pit mining has existed. It may take hundreds to thousands of years for some waste dumps to become "acid neutral" and stop leaching to the environment. The dumps are usually fenced off to

prevent livestock denuding them of vegetation. The open pit is then surrounded with a fence, to prevent access, and it generally eventually fills up with ground water. In arid areas it may not fill due to deep groundwater levels.<sup>[20]</sup> Instead of returning the land to its former natural state, it may also be reused, converting it into recreational parks or even residential/mixed communities.[21]



An open-pit sulfur mine at <u>Tarnobrzeg</u>, Poland

## Typical open cut grades

<u>Gold</u> is generally extracted in open-pit mines at 1 to 5 ppm (parts per million) but in certain cases, 0.75 ppm gold is economical. This was achieved by bulk <u>heap leaching</u> at the <u>Peak Hill mine</u> in western <u>New South Wales</u>, near <u>Dubbo</u>, <u>Australia</u>.<sup>[22]</sup>

<u>Nickel</u>, generally as laterite, is extracted via open-pit down to 0.2%. <u>Copper</u> can be extracted at grades as low as 0.11% to 0.2%. Materials typically extracted from openpit mines include:

- <u>Bitumen</u>
- <u>Clay</u>
- <u>Coal</u>
- <u>Copper</u>
- <u>Coquina</u>
- <u>Chromite</u>
- <u>Diamonds</u>
- <u>Gravel</u> and <u>stone</u>
- <u>Granite</u>
- <u>Gritstone</u>
- <u>Gypsum</u>
- <u>Limestone</u>

- <u>Marble</u>
- <u>Metal ores</u>, such as <u>copper</u>, <u>iron</u>, <u>gold</u>, <u>silver</u> and <u>molybdenum</u>
- <u>Uranium</u>
- <u>Phosphate</u>

## See also

- List of open-pit mines
- <u>Closure problem</u> applied to open-pit mines for optimal extraction (not related to closing the mine)
- <u>Cut-and-cover</u> tunneling
- <u>Cut (earthmoving)</u>
- <u>Trench</u>
- Artisanal mining

## References

- Read "Evolutionary and Revolutionary Technologies for Mining" at NAP.edu .
- 2. "Mining" . Encyclopedia Britannica. Retrieved 2019-04-01.
- 3. "Mining" . Encyclopedia Britannica. Retrieved 2019-04-01.

- 4. Chen, Jianping; Li, Ke; Chang, Kuo-Jen; Sofia, Giulia; Tarolli, Paolo (2015-10-01). "Open-pit mining geomorphic feature characterisation". International Journal of Applied Earth Observation and Geoinformation. 42: 76–86. doi:10.1016/j.jag.2015.05.001. ISSN 0303-2434.
- 5. "Mining" . Encyclopedia Britannica. Retrieved 2019-04-01.

- Mark A. Prelas; Galina Popovici; Louis K. Bigelow (23 September 1997). Handbook of Industrial Diamonds and Diamond Films. CRC Press. pp. 496–. ISBN 978-0-8247-9994-6.
- 7. Mark A. Prelas; Galina Popovici;
  Louis K. Bigelow (23 September 1997). Handbook of Industrial
  Diamonds and Diamond Films. CRC
  Press. pp. 496–. ISBN 978-0-8247-9994-6.
- 8. "Mining" . Encyclopedia Britannica. Retrieved 2019-04-01.
- 9. "Mining" . Encyclopedia Britannica. Retrieved 2019-04-01.

10. "Open Pit Surface Mine" Mine Engineer Community (2000) accessed 19 December 2011

- G.E. Blight; A.B. Fourie; G.R. Wardle (1 January 1999). Geotechnics for Developing Africa: Proceedings of the 12th regional conference for Africa on soil mechanics and geotechnical engineering, Durban, South Africa, 25–27 October 1999. CRC Press. pp. 49–. ISBN 978-90-5809-082-9.
- 12. "Mining" . Encyclopedia Britannica. Retrieved 2019-04-01.

13. "Mining Waste" European Commission Environment (17 November 2011) accessed 19 December 2011

14. Huertas, José I.; Huertas, María E.;
Izquierdo, Sebastián; González,
Enrique D. (January 2012). "Air
quality impact assessment of
multiple open pit coal mines in
northern Colombia". Journal of
Environmental Management. 93 (1):
121–129.
doi:10.1016 (i jonymon 2011.09.007)

doi:10.1016/j.jenvman.2011.08.007 .

15. Huertas, José I.; Huertas, María E.; Izquierdo, Sebastián; González, Enrique D. (January 2012). "Air quality impact assessment of multiple open pit coal mines in northern Colombia". Journal of Environmental Management. **93** (1): 121–129.

doi:10.1016/j.jenvman.2011.08.007 .

16. Abdul-Wahab, Sabah; Marikar, Fouzul (2012-01-01). "The environmental impact of gold mines: pollution by heavy metals" . Open Engineering. 2
(2). doi:10.2478/s13531-011-0052-3 . ISSN 2391-5439 . 17. "Quarry Proprietors - The Welsh and English Entrepreneurs" . Slatesite.

- Walter Geller; Helmut Klapper; Wim Salomons (6 December 2012). Acidic Mining Lakes: Acid Mine Drainage, Limnology and Reclamation. Springer Science & Business Media. ISBN 978-3-642-71954-7.
- Vasudevan Rajaram; Subijoy Dutta; Krishna Parameswaran (30 June 2005). Sustainable Mining Practices: A Global Perspective. CRC Press. pp. 207–. ISBN 978-1-4398-3423-7.

20. "MINE REHABILITATION" Department of Mines and Petroleum (October 2006) accessed 19 December 2011

- 21. "Mines2Cities" The Mines2Cities Project (April 2016) accessed 19 April 2016
- 22. "Peak Hill Gold Mine" Major metallic mines, deposits & projects (2010) accessed 19 December 2011

#### External links

Wikimedia Commons has media related to <u>Open pit mining</u>.

- <u>The biggest, deepest and deadliest</u> <u>mines in the world</u>
- <u>Deepest open pit mines</u>

Retrieved from

"https://en.wikipedia.org/w/index.php?title=Openpit\_mining&oldid=929262990"

Last edited 3 months ago by Mikaka

Content is available under CC BY-SA 3.0 unless otherwise noted.